

Install Arduino IDE in Linux



The whole installation process is very simple, just open terminal and execute the command below:

```
sudo apt-get update && sudo apt-get install arduino arduino-core
```

Please note that the informations above could be outdated. All the latest and updated instructions can be found here:
<https://www.arduino.cc/en/Guide/Linux>